

# MERLIN™

THE ELECTRONIC WIZARD

---

TRY TO BEAT ME AT TIC-TAC-TOE

---

TEACH ME A TUNE IN MUSIC MACHINE

---

TEST YOUR MEMORY IN ECHO

---

BEAT THE DEALER AT BLACKJACK 13

---

BREAK MY CODE IN MAGIC SQUARE

---

TEST YOUR LOGIC IN MINDBENDER

---

 **PARKER  
BROTHERS**

Rules © 1978 Parker Brothers Div. of General Mills Fun  
Group, Inc., Beverly, Mass. 01915. Printed in U.S.A.

MERLIN is Parker Brothers trademark for its hand-held  
interactive electronic game equipment.

 **PARKER  
BROTHERS**



# MERLIN™

The Electronic Wizard  
from Parker Brothers  
For 1 or 2 Players  
Ages 7–Adult

## TECHNICAL INFORMATION ABOUT MERLIN

### BEFORE PLAYING, PLEASE READ THIS SECTION CAREFULLY

MERLIN™ is a remarkably intelligent computer. Through light and sound he plays six different games of chance, strategy, memory, logic and skill. You can even teach him to play music!

As you compete with him, you'll discover that MERLIN is very talkative. He speaks with a unique vocabulary of 20 electronic sounds. With these sounds he challenges you to a game, responds to your moves, and tells you when you've won, lost or tied. It won't take you long at all to become familiar with each of MERLIN's sounds.

Lights are part of the action, too! As you play, you'll see that MERLIN uses lights to keep track of your moves, to show you your score, and to remind you, when you've finished playing, that you haven't yet turned him off.

Are you ready to match wits with MERLIN? Here are the games he plays:

1. **Tic-Tac-Toe.** MERLIN's aggressive tactics will keep you on your toes in this famous strategy game.
2. **Music Machine.** Teach MERLIN to play a tune of up to 48 notes and rests.
3. **Echo.** Repeat a tune of random notes that MERLIN teaches you.
4. **Blackjack 13.** MERLIN is the dealer in this computerized version of the classic card game.
5. **Magic Square.** Try to form a square of 8 lights. This electronic puzzle changes constantly as you play.
6. **Mindbender.** Discover the computer's mystery number. This game of logic is the ultimate challenge — to win you'll have to read MERLIN's mind!

#### 1) PROPER CARE.

MERLIN's computer brain is made of many delicate electronic parts. Therefore:

- Never take MERLIN apart.
- Don't drop or jolt MERLIN.
- Take care not to get MERLIN wet.
- When pressing one of MERLIN's buttons, touch it **lightly** in the very **center**. Pressing hard is unnecessary and can damage the game.
- Don't use a pen or pencil to press the buttons; use your fingers **only**.

#### 2) BATTERIES.

MERLIN can be made completely portable if you power him with batteries. To do this you'll need 6 AA-size batteries. We strongly recommend that you use only **ALKALINE BATTERIES**: they will last much longer than regular carbon batteries.

#### 3) AC ADAPTOR.

With an AC adaptor you can run MERLIN on house current instead of batteries. However, **buy only an AC adaptor that meets the following specifications:**

- Nominal: 9 Volt DC at 75 milliamps
- Maximum: 10.5 Volt DC at 5 milliamps
- Minimum: 7.5 Volt DC at 150 milliamps

Not all 9-volt, 75-milliamp adaptors will satisfy the minimum and maximum specifications shown above. Certain ones will cause MERLIN to operate erratically. We therefore recommend that you bring your MERLIN to a store to test the AC adaptor that you're considering.

If you can't conveniently locate an AC adaptor that meets these specifications, you may order one from Parker Brothers by sending your name, address and a check or money order for \$7.95 to: Parker Brothers, P.O. Box 1006, Beverly, Mass. 01915. Attention: Consumer Response Dept.



#### 4) SIGNS OF WEAK BATTERIES.

Unlike an AC adaptor, batteries eventually have to be replaced. Therefore, if ever you find that **MERLIN is not working properly, you probably need new batteries.** Any one of the following signs will indicate the need for new batteries:

- a) When you turn MERLIN on, no lights will flash.
- b) When you turn MERLIN on, all of the lights will shine steady.
- c) As you play, you'll hear a continuous sound.
- d) As you play, the keyboard won't respond as it should.

If any of these problems occur with **new** batteries, check to make sure that you've installed them correctly.

---

## TIC-TAC-TOE

### OBJECT:

To be the first to occupy three squares in a row – horizontally, vertically or diagonally.\*

### PREPARATION:

Press NEW GAME. Then press #1. The #10 light will blink, indicating that the game is on.

### PLAYING:

You and MERLIN take turns occupying one square at a time. Either of you may make the first move.

- a) To occupy a square yourself, press any unlighted square from 1 to 9. The square you choose will **blink**.
- b) MERLIN will take his turn when you press COMPUTER TURN. The square he chooses will shine **steady**.

### WINNING:

The winner is the first to occupy three squares in a row.

If you win – with three blinking lights in a row – MERLIN will make the WIN sound.

If MERLIN wins – with three steady lights in a row – he will make the LOSE sound.

If neither of you wins, MERLIN will make the TIE sound.

### CONTINUING:

To play Tic-Tac-Toe again, press SAME GAME.

\*In this classic strategy game your opponent is MERLIN, not another person.

---

## MUSIC MACHINE

### OBJECT:

To teach MERLIN a tune and then be entertained as he plays it back to you.

### PREPARATION:

Press NEW GAME. Then press #2.

### PLAYING:

Buttons 2-9 are the musical scale: do, re, mi, fa, sol, la, ti, do.

Button #1 is low "sol" – one octave lower.

Button #10 is high "re" – one octave higher.

Button 0 is a rest – each time you press it, MERLIN will pause 1 beat. (Because it's a rest, this button makes no sound when you press it.)

MERLIN can learn a tune of up to 48 notes and rests. While you're composing, however, don't worry if you can't remember how many buttons you've pressed. MERLIN will let you know – with the LOSE sound – when you've pressed a total of 48 buttons.

After you've finished composing a tune, press COMPUTER TURN and enjoy your music.

### CONTINUING:

- a) To play the same tune again, press COMPUTER TURN.
- b) To compose a different tune, press SAME GAME and start again.
- c) After MERLIN stops playing your tune, you can then continue that tune yourself by press-

ing the appropriate buttons. The extra notes that you play will not become a part of the tune that you just taught MERLIN to play.

Here are some tunes that you can teach MERLIN to play. Press the buttons in the order in which they appear.

### IT CAME UPON THE MIDNIGHT CLEAR

2-7-0 4-6-5 3-2-0 3-2-0 2-3-4 5-5-6  
7-6-0 0-0-0- 2-7-0 4-6-5 3-2-0 3-2-0  
2-3-0 3-4-3 2-5

### JINGLE BELLS

4-4-4 0-4-4 4-0-4 6-2-3 4-0-0 0-5-5  
5-5-5 4-4-4 6-6-5 3-2

### KNICK KNACK PADDYWHACK

6-4-6 0-6-4 6-0-7 6-5-4 3-4-5 4-6-2  
2-2-2 4-6-0 6-3-3 5-4-3 2

### LONDON BRIDGE

6-7-6 5-4-5 6-0-3 4-5-0 4-5-6 0-6-7  
6-5-4 5-6-0 3-0-6 0-4-2

### MARY HAD A LITTLE LAMB

4-3-2 3-4-4 4-0-3 3-3-0 4-6-6 0-4-3  
2-3-4 4-4-4 3-3-4 3-2

### OLD FOLKS AT HOME

4-0-3 2-4-3 2-0-9 0-7-9 0-0-6 0-0-4  
0-2-0 3-0-0 0-4-0 3-2-4 3-2-0 9-0-7  
9-0-0 6-0-4 2-3-0 3-0-2

### ON TOP OF OLD SMOKEY

2-2-4 6-9-0 0-7-0 0-0-0 7-5-6 7-6-0  
0-0-0 2-2-4 6-6-0 0-3-0 0-0-0 4-5-4  
3-2

### RED RIVER VALLEY

1-2-4 0-4-4 4-0-3 4-3-2 0-0-0 0-1-2  
4-0-2 4-6-0 5-4-3 0-0-0 0-0-6 5-4-0  
4-3-2 0-3-4 6-5-0

### ROW ROW ROW YOUR BOAT

2-0-2 0-2-3 4-0-4 3-4-5 6-0-0 0-9-9  
6-6-4 4-2-2 6-5-4 3-2

### A ROVIN'

6-7-0 5-7-6 0-4-6 5-4-3 2-4-2 1-1-2  
3-4-5 6-9-7 5-4-0 3-0-2

### AULD LANG SYNE

1-2-0 0-2-2 0-4-0 3-0-0 2-3-0 4-0-2  
0-0-2 4-0-6 0-7-0 0-0-0 0-7-0 6-0-0  
4-4-0 2-0-3 0-0-2 3-0-4

### BEETHOVEN'S 9TH

4-4-5 6-6-5 4-3-2 2-3-4 4-3-3 0-4-4  
5-6-6 5-4-3 2-2-3 4-3-2 2-0-3 3-4-2  
3-5-4 2-3-5 4-3-2 3-1

### BLOW THE MAN DOWN

6-7-6 4-2-4 6-7-6 4-0-0 6-0-0 7-0-0  
5-4-5 3-0-0 5-6-5 3-1-3 5-6-5 3-0-0  
6-6-6 6-0-5 4-3-4 2

### CLEMENTINE

2-2-2 0-1-0 4-4-4 0-2-0 2-4-6 0-0-6  
5-4-3 0-0-0 3-4-5 0-5-0 4-3-4 0-2-0  
2-4-3 0-0-1 2-3-2

### COCKLES AND MUSSELS

1-2-2 2-2-4 2-3-3 3-3-5 3-6-4 2-6-4  
2-2-3 4-3-0 1-2-2 2-2-4 2-3-3 3-3-5  
3-6-4 2-6-4 2-3-2 3-2

### FRERE JACQUES

2-3-4 2-2-3 4-2-4 5-6-0 4-5-6 0-6-7  
6-5-4 0-2-0 6-7-6 5-4-0 2-0-2 0-1-0  
2-0-0 0-2-0 1-0-2



## SHENANDOAH

2-2-2 0-0-3 4-5-7 0-6-0 0-0-9 8-7-0  
0-6-7 6-4-6 0-6-7 7-7-0 0-4-6 4-3-2  
0-1-2 3-4-2 3-2

## SILENT NIGHT

6-0-0 7-6-0 4-0-0 0-6-0 0-7-6 0-4-0  
0-0-10 0-0-10 0-8-0 0-0-9 0-0-9 0-6-0  
0-9-0 6-4-6 0-5-0 3-0-2

## TWINKLE TWINKLE LITTLE STAR

2-2-6 6-7-7 6-0-5 5-4-4 3-3-2 0-6-6  
5-5-4 4-3-0 2-2-6 6-7-7 6-0-5 5-4-4  
3-3-2

## WE THREE KINGS

7-0-6 5-0-3 4-5-4 3-0-0 7-0-6 5-0-3  
4-5-4 3-0-0 5-0-5 6-0-6 7-0-7 9-7-6  
5-0-5 4-0-4 3

---

# ECHO

### OBJECT:

To repeat a tune of random notes that MERLIN plays to you.

### PREPARATION:

Press NEW GAME. Then press #3. Both the 0 and 10 lights will blink. This is MERLIN's way of asking you to select the number of notes in his tune. To do this, press one button from 1 to 9. The higher the number you select, the longer and more difficult the tune will be. Then press COMPUTER TURN and MERLIN will play you the tune.

**EXAMPLE:** To select a game of average difficulty, press #5. Then press COMPUTER TURN and MERLIN will play you a 5-note tune. To win, you must repeat MERLIN's tune **exactly** as he played it.

### PLAYING:

1. As MERLIN plays his tune, listen carefully to the notes and watch closely the lights that accompany them.

2. When MERLIN stops playing, try to repeat the exact order of notes and accompanying lights by pressing the appropriate buttons.

a) If you press a button in the correct order, it will light and sound its note.

b) If you press a button out of order, you'll hear a buzz. Even if MERLIN buzzes you, continue guessing — starting with the **next** note — until you've pressed the appropriate number of buttons.

### SCORING:

a) If all of your notes are in the correct order, MERLIN will make the WIN sound.

b) Otherwise MERLIN will make the LOSE sound and will show you — by lighting one numbered button — how many errors you've made.

### CONTINUING:

To play the same tune again, press COMPUTER TURN. To try a different tune — even one of equal difficulty — press SAME GAME, press the desired level of difficulty, then press COMPUTER TURN.

### COMPETING AGAINST ANOTHER PERSON:

On your turn, keep the buttons hidden from view. When you've finished guessing and have seen your score, hand MERLIN to your opponent. Your opponent presses COMPUTER TURN and tries to repeat the very same tune. The winner is the one to repeat MERLIN's tune with the fewer errors.

---

# BLACKJACK 13

In this game, buttons 1 through 10 represent a deck of 10 cards.

### OBJECT:

To acquire the higher hand of 13 or less.

### PREPARATION:

Press NEW GAME. Then press #4.

### PLAYING:

1. MERLIN is the dealer. Both of you start the game with a hand of one card. The blinking light shows your hand; the steady light shows



# MAGIC SQUARE

MERLIN's hand. You (not MERLIN) also start the game with a stake of five chips.

2. On your turn you may either "hit" your hand or "stand."

a) If you want to "hit" your hand—to ask for another card—press HIT ME.

If your hand then totals less than 13, you may again either "hit" or "stand."

If your hand totals more than 13, you "bust" and immediately lose.

b) If you want to "stand"—to take no more cards—press COMPUTER TURN.

3. MERLIN then plays his hand according to the following strategy:

a) If his hand is less than 10, he hits. If he "busts," you win.

b) If his hand is 10 or more, he stands. When he stands, MERLIN then compares his hand with yours in order to determine a winner. At no other time can MERLIN see your hand.

## WINNING:

The winner is the player with the higher hand of 13 or less. Along with the WIN, LOSE or TIE sound, MERLIN will also show each card that was drawn in the hand.


## CONTINUING:

This game consists of multiple hands. To play another hand, press SAME GAME and watch the numbered buttons closely. MERLIN will very briefly light one number to show you how many chips you have. (You receive one chip for each hand that you win; you lose one chip for each hand that MERLIN wins.) Then, to start the next hand, MERLIN will deal each of you one card.

If you accumulate ten chips, you break the bank and win the game. If you lose all of your chips, you go broke and MERLIN ends the game. To start a new game, press NEW GAME, then press #4. You'll start again with 5 chips.

## OBJECT:

To form a square of eight lights by lighting buttons 1, 2, 3, 4, 6, 7, 8 and 9. At the same time, you will have to turn off button #5—the middle button.



## PREPARATION:

Press NEW GAME. Then press #5 and watch the numbered buttons closely. MERLIN will very briefly show you the Magic Square. Then you'll see a random display of one or more blinking lights.\*

## PLAYING:

Press buttons 1-9, in any order, until you've formed the Magic Square. When you succeed, MERLIN will flash the Magic Square and will make the WIN sound.

## MERLIN's Secret Code

As you play Magic Square, you'll see that the nine numbered buttons affect each others' lights in certain predictable patterns. Each time you press one of the buttons, certain lights always come on and other lights always go off. To form the Magic Square, you'll find it helpful to understand these patterns—MERLIN's secret code.

**EXAMPLE:** Button #1 always affects lights 1, 2, 4 and 5 in a predictable pattern. That is, when you press button #1, it **reverses** these lights: the ones that were off will go on and the ones that were on will go off. In this same way each of the other numbered buttons **reverses** other groups of lights. After you've played a few times you'll discover which buttons reverse which groups of lights.



## CONTINUING:

To play Magic Square again, press SAME GAME and start pressing buttons 1-9.

## CHALLENGING ANOTHER PERSON — FOR EXPERTS ONLY

On your turn, keep the buttons hidden from view. After completing the Magic Square, take it apart by secretly pressing up to three **different** buttons from 1 to 9. Tell your opponent how many buttons you just pressed. Then challenge your opponent to recreate the Magic Square by pressing the same number of buttons. To succeed, your opponent will have to press, in **any** order, the **same** buttons that you pressed.

**EXAMPLE:** After completing the Magic Square, take it apart by secretly pressing buttons 4, 9 and 2. Then challenge your opponent to try to recreate the Magic Square by pressing only three buttons. To succeed, your opponent will have to press buttons 4, 9 and 2 in any order.

When your opponent recreates the Magic Square, the two of you then reverse roles. In other words, your opponent secretly presses any three **different** buttons and challenges you in the same way. The winner is the one to meet the challenge. If each of you requires more than three guesses, the winner is the one to recreate the Magic Square in the fewer tries.

\*At this point, or at other times during the game, buttons 1-9 may all go dark. If this happens, button #10 will blink, indicating that the game is still on.

---

# MINDBENDER

## OBJECT:

To discover the mystery number in MERLIN's computer brain.

## PREPARATION:

Press NEW GAME. Then press #6. The 0 and 10 lights will blink. This is MERLIN's way of asking you to select the length of his mystery number. To do this, press one button from 1 to 9. The higher the number you press, the longer and more difficult the mystery number will be. (For your first game,

we recommend that you press #2 — a 2-digit mystery number.)

**EXAMPLE:** Let's say that you press #4. In secret, MERLIN will then select a random, 4-digit number. Through a process of deduction, you try to discover all four digits in the correct order.

To keep track of your guesses, use a pencil and a piece of paper.

## PLAYING:

1. Try to discover the mystery number by entering guesses that correspond to the length of the number. **EXAMPLE:** If the mystery number has four digits, enter each guess by pressing any four buttons from 1 to 9 in any order that you prefer. You might want to guess 2-3-8-2, or 1-6-9-5, or 4-4-4-4, etc.

2. MERLIN will then let you know how accurately you guessed:

- a) If you guessed the **correct** digits in the **correct** order, MERLIN will make the WIN sound and will flash a light for each digit in the number.
- b) If **any part** of your guess was **incorrect**, MERLIN will make the LOSE sound and will show you how close your guess was:

If **none** of the digits in your guess is a part of his number, MERLIN will blink the #10 light.

For each **correct** digit that is **also** in the correct order, MERLIN will show a blinking light.

For each **correct** digit that is **not** in the correct order, MERLIN will show a steady light.

**The blinking and steady lights will start at #1 and will not necessarily correspond either to the digits that you've guessed or to MERLIN's mystery number.**

**EXAMPLE:** Let's say that you ask MERLIN to select a 4-digit mystery number. In secret, MERLIN selects the number 9-2-4-2.

- a) If one of your guesses is 1-3-5-7, MERLIN will blink the #10 light. This light tells you that none of the digits in your guess was correct.
- b) If one of your guesses is 1-2-3-4, MERLIN will show a blinking light at #1 and a steady light at #2. These lights tell you that two of the

digits in your guess were correct and that one of them was in the correct order. Now it's up to you to determine which two digits you guessed correctly and which one of them was in the correct order.

c) If one of your guesses is 4-2-2-9, MERLIN will show a blinking light at #1 and steady lights at #s 2, 3 and 4. These lights tell you that all of the digits in your guess were correct and that one of them was in the correct order.

If you entered this guess right after the previous guess (1-2-3-4), you'd gain some important clues about the mystery number. First, you'd see that "2" is the only digit that appears in both guesses in the same order. You'd know, therefore, that the blinking light represents this digit. You'd also see that the "4" is the only other digit that appears in both guesses: fourth position in one guess, first in the other. You'd know, therefore, that the "4" must fall in either the second or third position of the 4-digit mystery number.

d) If you guess 9-2-4-2, MERLIN will show blinking lights at #s 1, 2, 3 and 4 and will also make the WIN sound.

### SCORING:

After you win, press SAME GAME. MERLIN will briefly shine a light showing the number of guesses you took. Remember, however, MERLIN can score only up to 10 guesses.

### COMPETING AGAINST ANOTHER PERSON:

On your turn keep the buttons hidden from view. After discovering the mystery number and learning your score, hand MERLIN to your opponent. Your opponent presses SAME GAME and also tries to determine the mystery number. The winner is the one to learn the mystery number in the fewer guesses.

PARKER BROTHERS, DIVISION OF GENERAL MILLS FUN GROUP, INC. (PARKER BROTHERS) hereby warrants, subject to the conditions set forth below, that if the components of this product prove defective because of improper workmanship or material:

During the period of 180 days from the date of original purchase, PARKER BROTHERS will repair or replace the product, without charge for parts or labor, or refund the purchase price, at Parker Brothers' option.

### CONDITIONS:

1. Registration: The enclosed registration card must be mailed to PARKER BROTHERS (address: 50 Dunham Rd., Beverly, MA 01915, Attention: Consumer Response Dept.) within 10 days after the date of original purchase at retail. If this registration card is not mailed, the retail sales receipt or other proof of purchase must be provided for work to be done under the terms of this LIMITED WARRANTY.
2. Proper Delivery: The product must be shipped, prepaid, or delivered to PARKER BROTHERS (address: 190 Bridge Street, Salem, MA 01970, Attention: Quality Control Dept.) for servicing either in the original package or in a similar package providing an equal degree of protection.
3. Unauthorized Repair, Abuse, etc. The product must not have been previously altered, repaired or serviced by anyone other than PARKER BROTHERS; the product must not have been subjected to an accident, misuse, abuse or have been operated contrary to the instructions contained in the accompanying manual.

**EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ALL IMPLIED WARRANTIES MADE BY PARKER BROTHERS IN CONNECTION WITH THE PRODUCT, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD OF 180 DAYS FROM THE DATE OF ORIGINAL PURCHASE; AND NO WARRANTIES, WHETHER EXPRESSED OR IMPLIED, INCLUDING THE WARRANTY OF MERCHANTABILITY, SHALL APPLY TO THIS PRODUCT AFTER SAID PERIOD. SHOULD THIS PRODUCT PROVE DEFECTIVE IN WORKMANSHIP AND MATERIAL, THE CONSUMER'S SOLE REMEDY SHALL BE SUCH REPAIR, REPLACEMENT OR REFUND AS IS HEREIN ABOVE EXPRESSLY PROVIDED; AND UNDER NO CIRCUMSTANCES SHALL PARKER BROTHERS BE LIABLE FOR ANY LOSS OR DAMAGE, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT.**

Some states do not allow limitations on how long an implied warranty lasts, or the exclusions or limitations of incidental or consequential damages, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

---

We will be happy to answer questions about this game. Write to: Consumer Response Dept., Parker Brothers, 50 Dunham Road, Beverly, Mass. 01915.